



21" Deep or 18" Deep option.

Basin placement range varies with brand and model. Shown is for Kohler 2210. Offset basin placement not recommended for 30" wide vanities.

30" Vanity No Side Drawers

30" wide
34 1/2" tall
21" or 18" front-to-back

