



FORO PER INSERIMENTO TASSELLO A MURO Ø30
 POSITIONING OF FASTENERS FOR FIXING TO WALL
 FASTNERS SHOULD BE SECURED IN STUDS OR HEADERS PLACES BEHIND THE UNIT
 TROU POUR LA CHEVILLE A MUR

