



Drawers:  
 16" Deep  
 A 3 3/4" High  
 B 4 3/4" High

21" Deep or 18" Deep option.

Basin placement range varies with brand and model. Shown is for Kohler 2210.  
 Offset basin placement not recommended for 30" wide vanities.

### 30" Vanity Right Hand or Left Hand Drawers

30" wide  
 34 1/2" tall  
 21" or 18" front-to-back

