

INSTRUCTIONS FOR FITTING MIXERS TO FLOOR STANDARDS
FOR 50mm (2") DIAMETER FLOOR STANDARDS

REF. 4310/3310

1. Fit bracing kit rings to floor standards.
2. Screw bush onto long thread of extended offsets and lock in position with backnut.
3. Fit 750mm minimum length of copper tube to tail and make joint.
4. Screw complete assembly into 50mm standards.
5. Drill hole to suit 22mm copper in floor boards and screw assembly to floor.

