



- | | |
|-------------------------------------|---|
| A. Decorative frame | J. On/off switch for 2 nd uppermost lamp |
| B. Coated glass plate | K. On/off switch for middle lamp |
| C. Operating panel | L. On/off switch for lowest 2 lamps |
| D. Warnings | M. Time display |
| - Warning texts | N. Cool down display |
| - Warning images | O. Display indicating switched-on tanning lamps |
| E. Minus timer button | P. Protective glasses (2 pairs) |
| F. Plus timer button | Q. Sunshower cleaning pad |
| G. Start button | R. Sunshower Glass Cleaner |
| H. Stop button | S. Sunshower After Care |
| I. On/off switch for uppermost lamp | T. Exposure schedule |