



FEATURES:

- Brass construction with choice of 21 finishes
- Single Handle Control cycles from Cold to Hot
- High temperature Limit Stop
- 20 psi minimum operating pressure, 125psi maximum

**CONTACT US:**



If you need assistance with installation, replacement parts or have any questions regarding your Rubinet product, please call a Customer Service representative at: 905-851-6781 toll free 1-800-461-5901 or visit www.rubinet.com



150824**THE Rubinet** FAUCET COMPANY**ASSEMBLY INSTRUCTION****4YFML or C****VALVE ONLY PRESSURE BALANCE WITH STOPS****4YFML****4YFMC****REMOVAL OF FIXTURE:**

Always turn the water supply off before removing the existing fixture or disassembling a valve. Open all handles to relieve water pressure and to ensure that the water has been successfully turned off.


CARE OF FIXTURE:

The use of warm water and a soft cloth is all that is required to clean Rubinet products. The patina of our living finishes (Oil Rubbed Bronze & Tuscan Brass) will change as a result of normal use. Applying Mineral Oil on occasion will create a softer look, subtle color changes and character.






Refer to the protective cover (mounting guide) markings for proper installation depth. This cover must remain in place when plastering and/or tiling etc.



2




* Make sure the stop ring is in closed position as shown above before final trim is installed


3

HOT LIMIT STOP INSTALLATION

1



2



3

