

ASSEMBLY INSTRUCTION**5A/5ERTL or Q**

ROMAN TUB FILLER

**5ARTL (3/4" Valve)****5ERTL (1/2" Valve)****5ARTQ (3/4" Valve)****5ERTQ (1/2" Valve)****REMOVAL OF FAUCET:**


Always turn the water supply off before removing the existing faucet or disassembling a valve. Open both faucet handles to relieve water pressure and to ensure that the water has been successfully turned off.

CARE OF FAUCET:


The use of warm water and a soft cloth is all that is required to clean Rubinet products. The patina of our living finishes (Oil Rubbed Bronze & Tuscan Brass) will change as a result of normal use. Applying Mineral Oil on occasion will create a softer look, subtle color changes and character.

ROMAN TUB FILLER

5A/5ERTL or Q




1




* **SPACER NOT NEEDED** when the deck thickness is **more than 1 1/2"**


2




* Do not fasten the Nut too tight for handle alignment later







*Turn the cartridge valves to closed position before installing handles





FEATURES:

- Brass construction with choice of 21 finishes
- Two Lever or Square Handles
- Quarter turn ceramic disc cartridges
- Flexible Stainless Steel supply hoses
- Flow rate: Full Flow



CONTACT US:

If you need assistance with installation, replacement parts or have any questions regarding your Rubinet product, please call a Customer Service representative at: 905-851-6781 toll free 1-800-461-5901 or visit www.rubinet.com